

Beam Propagation

BPM, Gauss Modes,
Transfer Matrix Method

Paraxial Approximation

Motivation: In several applications, one has to simulate light propagating in one direction (z-direction):

- laser simulation
- light in fibers

Ansatz: E-field behaves like

$$E(x, y, z) = \exp(-ik_0 z) \Psi(x, y, z)$$

Here,

- $\Psi(x, y, z)$ is the amplitude of the wave and
- k_0 an average value of the wave number.

Paraxial Approximation

Inserting $E(x, y, z) = \exp(-ik_0 z)\Psi(x, y, z)$

in the scalar Helmholtz equation

$$(\Delta + k^2)E(x, y, z) = 0$$

yields $-\Delta\Psi + 2ik_0 \frac{\partial\Psi}{\partial z} + (k_0^2 - k^2)\Psi = 0$

In paraxial approximation one neglects $\frac{\partial^2\Psi}{\partial z^2}$.
This leads to:

$$2ik_0 \frac{\partial\Psi}{\partial z} = \frac{\partial^2\Psi}{\partial x^2} + \frac{\partial^2\Psi}{\partial y^2} - (k_0^2 - k^2)\Psi$$

Beam Propagation Method

Discretization of $2ik_0 \frac{\partial \Psi}{\partial z} = \frac{\partial^2 \Psi}{\partial x^2} + \frac{\partial^2 \Psi}{\partial y^2} - (k_0^2 - k^2) \Psi = 0$

leads to

$$2ik_0 \frac{\Psi^{l+1} - \Psi^l}{\Delta z} = \frac{1}{2} (L_h \Psi^{l+1} + L_h \Psi^l)$$


where $L_h \Psi$ is a spatial discretization of:

$$L(\Psi) := \frac{\partial^2 \Psi}{\partial x^2} + \frac{\partial^2 \Psi}{\partial y^2} - (k_0^2 - k^2) \Psi$$

Beam Propagation Method

The BPM methods performs the iteration:

$$\Psi^{l+1} = \left(E - \frac{\Delta z}{4ik_0} L_h \right)^{-1} \left(E + \frac{\Delta z}{4ik_0} L_h \right) \Psi^l$$



Gauss Modes

Assume $k=k_0$. Then, paraxial approximation leads to:

$$2ik_0 \frac{\partial \Psi}{\partial z} = \frac{\partial^2 \Psi}{\partial x^2} + \frac{\partial^2 \Psi}{\partial y^2}$$

One solution of this equation is the TEM00 Gauss mode:

$$E(x, y, z) = \frac{1}{q_0 + z} \exp \left(-ik \left(z + \frac{x^2 + y^2}{2(q_0 + z)} \right) \right)$$

where q_0 is a complex parameter.

Gauss Modes

The spot size at point z is defined to be the radius r such that E-field decreases by e^{-1} :

$$e^{-1} = \frac{|E(r, z)|}{|E(0, z)|}, \quad \text{where } r = \sqrt{x^2 + y^2}$$



A Gauss mode with parameter q has beam radius

$$w(z)^2 = \frac{\lambda}{\pi} \left(\text{Im}(q_0) + \frac{(\text{Re}(q_0) + z)^2}{\text{Im}(q_0)} \right)$$

Gaussian Modes

Gaussian mode TEM00:


$$E(x, y, z) = A \frac{1}{q_0 + z} \exp \left(-ik \left(z + \frac{x^2 + y^2}{2(q_0 + z)} \right) \right)$$




Gaussian Modes

High order Gaussian modes


$u_{TEM\ 00}$




$u_{TEM\ 01}$



$u_{TEM\ 10}$




$u_{TEM\ 11}$



$$r_m = r_{TEM\ 00} \sqrt{m+1}$$

ABCD Matrix Calculation


Propagation of ray through a lens:



$$\begin{pmatrix} r_{out} \\ m_{out} \end{pmatrix} = \begin{pmatrix} 1 & 0 \\ -\frac{1}{f} & 1 \end{pmatrix} \begin{pmatrix} r_{in} \\ m_{in} \end{pmatrix}$$

ABCD Matrix Calculation

Lenses, mirrors, and other optical elements are described by ABCD matrices.




$$\begin{pmatrix} r_{out} \\ m_{out} \end{pmatrix} = \begin{pmatrix} A & B \\ C & D \end{pmatrix} \begin{pmatrix} r_{in} \\ m_{in} \end{pmatrix}$$

- Ray matrices: Propagation of diode pump light.
- Wave optics: Gaussian mode analysis of resonator.

ABCD Matrix Calculation

Propagation of Gaussian modes through lenses, mirrors, and other optical elements, described by ABCD matrices:



Gaussian mode TEM00:

$$E(x, y, z) = A \frac{1}{q + z} \exp \left(-ik \left(z + \frac{x^2 + y^2}{2(q + z)} \right) \right)$$

Transfer Matrix Method (TMM)

Consider the 1D scalar Helmholtz equation

$$\frac{\partial^2 E}{\partial x^2} + k(x)^2 E = 0$$

on a layers with piecewise constant wave number k_i .

Example: Periodic change of refraction index k_1, k_2 :



Transfer Matrix Method (TMM)

On each layer the solution of scalar Helmholtz equation is:

$$E(x) = c_r \exp(-ikx) + c_l \exp(ikx)$$

On each layer this leads to the solutions:

$$E(x) = c_r^i \exp(-ik_i(x - l_{i-1})) + c_l^i \exp(ik_i(x - l_{i-1}))$$

where l_{i-1} is the location of the i-th layer

Transfer Matrix Method (TMM)

The transmission matrix of the i-th layer is:

$$\begin{pmatrix} c_r^{i+1} \\ c_l^{i+1} \end{pmatrix} = M_i \begin{pmatrix} c_r^i \\ c_l^i \end{pmatrix}$$



The total transmission matrix is: $M = \prod_{i=1}^n M_i$




$$\begin{pmatrix} c_r^{n+1} \\ c_l^{n+1} \end{pmatrix} = M \begin{pmatrix} c_r^1 \\ c_l^1 \end{pmatrix}$$

transmission matrix

$$\begin{pmatrix} c_r^{n+1} \\ c_l^1 \end{pmatrix} = S \begin{pmatrix} c_r^1 \\ c_l^{n+1} \end{pmatrix}$$

scattering matrix

Transfer Matrix Method (TMM)



$$\begin{pmatrix} c_r^{n+1} \\ c_l^{n+1} \end{pmatrix} = M \begin{pmatrix} c_r^1 \\ c_l^1 \end{pmatrix}$$

transmission matrix



$$\begin{pmatrix} c_r^{n+1} \\ c_l^1 \end{pmatrix} = S \begin{pmatrix} c_r^1 \\ c_l^{n+1} \end{pmatrix}$$

scattering matrix

Transfer Matrix Method (TMM)



Using the continuity of $E(x)$ and $E'(x)$ one obtains:

$$\begin{pmatrix} 1 & 1 \\ -k_{i+1} & k_{i+1} \end{pmatrix} \begin{pmatrix} c_r^{i+1} \\ c_l^{i+1} \end{pmatrix} = \begin{pmatrix} 1 & 1 \\ -k_i & k_i \end{pmatrix} \begin{pmatrix} \exp(-ik_i h_i) & 0 \\ 0 & \exp(ik_i h_i) \end{pmatrix} \begin{pmatrix} c_r^i \\ c_l^i \end{pmatrix}$$


Transfer Matrix Method (TMM)

Example: Periodic change of
refraction index k_1, k_2 on
layers of size $\lambda/4$:

Transmission:



$$n_1 = 3.275$$



$$n_1 = 3.220$$

$$n_0 = 3.277$$